




95108-30



95108-30			
RR DOOR			
LOCK			
1	M201059-4600	LOCK ASSY, RR DR, LH	1
1	M201059-4700	LOCK, RR DR, RH	1
2	M201059-2400	LINK, RR DOOR, LH	1
2	M201059-2500	LINK, RR DOOR, RH	1
3	M201059-0803	COVER, RR DOOR LOCK KNOB	2
4	M201059-3500	KNOB, RR DOOR LOCK, LH	1
4	M201059-3600	KNOB, RR DOOR LOCK, RH	1
5	M201059-0403	HANDLE ASSY, RR DOOR, INNER	2
7	M201059-4800	CABLE ASSY, RR DOOR	2
8	M201059-6200	STRIKER, RR DOOR LATCH	2
9	M201059-1200	HANDLE ASSY, RR DOOR OUTER, LH	1
9	M201059-1300	HANDLE ASSY, RR DOOR OUTER, RH	1
10	CV8119-2800	CLIP,RR DOOR INNER CABLE	2

2013-05

